



VARIABLE SPEED ELECTRIC FURNACE INSTALLATION INSTRUCTIONS

Table of Contents

VARIABLE SPEED ELECTRIC FURNACE SAFETY	1	Filter Specifications.....	5
INSTALLATION REQUIREMENTS	2	Make Electrical Connections	5
Tools and Parts	2	Complete Installation.....	10
Location Requirements	2	SEQUENCE OF OPERATION	12
Installation Configurations	3	ELECTRIC FURNACE MAINTENANCE	13
Electrical Requirements	4	ASSISTANCE OR SERVICE	13
Duct Work Requirements.....	4	Accessories	13
INSTALLATION INSTRUCTIONS	4	WARRANTY	14
Inspect Shipment	4		
Install Duct Work.....	5		

VARIABLE SPEED ELECTRIC FURNACE SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING." These words mean:

⚠ DANGER

You can be killed or seriously injured if you don't immediately follow instructions.

⚠ WARNING

You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

INSTALLATION REQUIREMENTS

These instructions are intended to be a general guide and do not supersede any local or national codes. Installation must conform with the local building codes and with the latest editions of the National Electric Code.

Read the entire instruction manual before starting the installation. All models are designed for indoor installations only.

The unit is shipped from the factory completely assembled to be configured for upflow, counterflow, right to left or left to right air flow depending on the installation.

Do not remove the cabinet knockouts until it has been determined which knockouts will need to be removed for the installation.

The electric furnace may be used with an optional modular evaporator coil (WME) in upflow, counterflow, or horizontal applications. See "Airflow Configuration Options" for acceptable system configurations. The mounting plates and the necessary hardware to connect the electric furnace and modular evaporator coil cabinets together are included with this product.

An optional electric heater may be installed in this cabinet.

Select the final installation position which best suits the site conditions. Select any accessories that are to be included in the installation. Consider required clearances for the accessories to be used and the access space, filters, duct work, wiring, and service accessibility. For the electric heater accessory, refer to the electric heater rating plate for specific information regarding electrical supply.

Tools and Parts

Assemble the required tools and parts before starting installation. Read and follow the instructions provided with any tools listed here.

Tools Needed:

- ¼ in. Nut driver
- Level
- Screwdriver
- Adjustable wrench
- Tape measure

Parts Needed:

Check local codes and HVAC supplier. Check existing electrical supply, and read "Electrical Requirements," "Location Requirements," and "Install Duct Work."

- UL listed wire nuts

Location Requirements

⚠ WARNING



Explosion Hazard

Keep flammable materials and vapors, such as gasoline, away from electric furnace.

Place electric furnace so that heating elements are at least 18 inches (46 cm) above the floor for a garage installation.

Failure to follow these instructions can result in death, explosion, or fire.

Installation Configurations

For ease in installation, it is best to make any necessary coil configuration changes before setting the electric furnace in place. See "Installation Configuration Options."

Vertical Installations

Upflow/Counterflow

The electric furnace must be supported on the bottom only and set on solid floor or field supplied supporting frame. Securely attach the electric furnace to the floor or supporting frame.

Horizontal Installations

Horizontal installations can be left-hand or right-hand air supply. The cabinet must be supported by the building structure to ensure cabinet integrity. Ensure that there is adequate room to remove the blower access panel if installing in the horizontal position.


Suspended Cabinet Installation

NOTE: Electric furnaces cannot be installed in such a way that the blower access panel is facing up or down.

- The suspending means must be field fabricated, and should consist of two "cradles" made by attaching two rods to a length of angle iron or suitable gauge steel.
- Locate the cradles so that they are as close as possible to the ends of the electric furnace (this will provide access for removal of major components such as the blower assembly).
- Provide enough clearance between the suspension rods and the electric furnace to allow removal of the blower access panel.

Installation Configuration Options

NOTE: Typical installations with optional WME modular evaporator coil are shown.



Electrical Requirements

WARNING



Electrical Shock Hazard

Electrically ground furnace.

Connect ground wire to green pigtail lead.

Failure to do so can result in death or electrical shock.

NOTE: Use copper conductors only.

- All field wiring must be done in accordance with National Electrical Code, applicable requirements of UL and local codes.
- Electrical wiring, disconnect means and overcurrent protection are to be supplied by the installer. Refer to the electric furnace rating plate for maximum overcurrent protection, minimum circuit ampacity, as well as operating voltage.
- The power supply must be sized and protected according to the specifications supplied on the product.
- This electric furnace is factory configured for 240 Volt, single phase, 60 cycles. For 208 Volt applications, see “208 Volt Conversion” in the “Make Electrical Connections” section.
- For optional electric heater applications, see “Accessories.” Refer to the instructions provided with the accessory for proper installation.

Duct Work Requirements

- Install the conditioned air plenum, ducts and air filters (not provided) in accordance with NFPA 90B Standard for the Installation of Warm Air Heating and Air-Conditioning Systems (latest edition).
- The electric furnace is provided with flanges for the connection of the plenum and ducts.
- Air filters must be listed as Class 2 furnace air filters.
- Supply and return duct work must be adequately sized to meet the system’s air requirements and static pressure capabilities. Duct work should be insulated with a minimum of 1 in. thick insulation with a vapor barrier in conditioned areas or 2 in. minimum in unconditioned areas.
- Supply plenum should be the same size as the flanged opening provided around the blower outlet and should extend ideally at least 3 ft from the electric furnace before turning or branching off plenum into duct runs. The plenum forms an extension of the blower housing and minimizes air expansion losses from the blower.

INSTALLATION INSTRUCTIONS

Inspect Shipment

WARNING

Excessive Weight Hazard

Use two or more people to move and install furnace.

Failure to do so can result in back or other injury.

The electric furnace is completely factory assembled, and all components are performance tested. Each unit consists of a blower assembly and controls in an insulated, galvanized factory finished enclosure. Knockouts are provided for electrical wiring entrance.

1. Check the unit rating plate to confirm specifications are as ordered.
2. Upon receipt of equipment, carefully inspect it for possible shipping damage. Take special care to examine the unit inside the carton if the carton is damaged.

If damage is found, it should be noted on the carrier’s freight bill. Damage claims should be filed with the carrier immediately. Claims of shortages should be filed with the seller within 5 days.

NOTE: If any damages are discovered and reported to the carrier, do not install the unit as your claim may be denied.

Install Duct Work

IMPORTANT:

- Install duct work in accordance with NFPA 90B and any local codes.
- Connect supply air duct to the flange on top of the electric furnace. If an isolation connector is used, it must be non-flammable.
- A return air duct system is recommended.

Non-Ducted Return Closet Installation

The electric furnace can be installed in a closet with a false bottom to form a return air plenum or be installed with a return air plenum under the electric furnace. Louvers or return air grilles are field supplied. Local codes may limit application of systems without a ducted return to single-story buildings.

- Install louvers in a closet. Use the free area of louver or grille to determine the size opening required to provide the free area for metal louvers or grilles. See "Filter Requirements" for minimum free area required.
- If the free area is not known, assume a 25% free area for wood or a 75% free area for metal louvers or grilles.
- If the return air plenum is used, the return air grille should be immediately in front of the opening in the plenum to allow for the free flow of return air.
- When not installed in front of the opening, there must be adequate clearance around the electric furnace to allow for the free flow of return air.

Filter Specifications

Filters are not supplied with these air handlers. It is the installer's responsibility to install properly sized filters in accordance with the "Minimum Filter Requirements Chart."

- The filter size is determined by the "Nominal Tons Air Conditioning & Nominal Airflow" (see chart).
- Areas and dimensions shown for cleanable filters are based on filters rated at 600 ft per minute face velocity.
- Typical filter sizes are shown; however, any combination of filters whose area equals or exceeds the minimum area shown is satisfactory.

Minimum Filter Requirements Chart

Nominal Tons Air Conditioning & Nominal Airflow	Square Inch Surface Area & Nominal Size		Minimum Return Air Free Area
	Disposable Filters	Cleanable Filters	
Up to 2 Tons 800 - 900 CFM	432 sq. in. 20 in. x 25 in.	260 sq. in. 15 in. x 20 in.	260 sq. in.
2½ Tons 900-1000 CFM	480 sq. in. 20 in. x 30 in.	288 sq. in. 14 in. x 25 in.	288 sq. in.
3 Tons 1300 - 1500 CFM	576 sq. in. *14 in. x 25 in.	346 sq. in. 16 in. x 25 in.	346 sq. in.
3½ Tons 1300 - 1500 CFM	672 sq. in. *16 in. x 25 in.	404 sq. in. 20 in. x 25 in.	404 sq. in.
4 Tons 1500 - 1700 CFM	768 sq. in. *20 in. x 25 in.	461 sq. in. 20 in. x 25 in.	461 sq. in.
5 Tons 1900 - 2100 CFM	960 sq. in. *20 in. x 30 in.	576 sq. in. 24 in. x 25 in.	576 sq. in.

* 2 disposable filters required for these units

If a central return air filter-grille is used, the electric furnace does not require a filter.

To install a filter at the electric furnace only, use the following kits:

- AEFFLTS-1 Filter Kit for 17.5 in. x 22.5 in. cabinets
- AEFFLTM492-1 Filter Kit for 22 in. x 21.5 in. cabinets
- AEFFLTL493-1 Filter Kit for 22 in. x 26 in. cabinets

Make Electrical Connections

208/240 Volt Installations

⚠ WARNING



Electrical Shock Hazard


Disconnect all power supplies before servicing.

Replace all parts and panels before operating.

Failure to do so can result in death or electrical shock.

1. Disconnect all power supplies.
2. Remove the blower access panel.
3. Route the field supply wires to the electric furnace electrical connection box.

- Using UL listed wire nuts, connect the field supply wires to the electric furnace (black to black and yellow to yellow).



⚠ WARNING


Electrical Shock Hazard

Electrically ground furnace.

Connect ground wire to green pigtail lead.

Failure to do so can result in death or electrical shock.

- Connect ground wire to green pigtail lead.



1. Connect black to black
2. Connect yellow to yellow
3. Connect green to green

- Replace the blower access panel.

208 Volt Conversion

⚠ WARNING

Electrical Shock Hazard

Disconnect all power supplies before servicing.



Replace all parts and panels before operating.

Failure to do so can result in death or electrical shock.



- Disconnect all power supplies.
- Remove the blower access panel.
- Move the 2 connected black transformer leads from the 240 Volt terminal on the transformer to the 208 Volt terminal on the transformer. See "Wiring Diagram - Blower".

Low Voltage Connections



Cooling Application




Heat Pump Application




Electric Heat Only



Blower Only



Wiring Diagram - Blower



- LINE VOLTAGE FACTORY
- - - LINE VOLTAGE FIELD
- LOW VOLTAGE FACTORY
- - - LOW VOLTAGE FIELD

Complete Installation

Pre-Start Check

- Is unit properly located, level, secure, and serviceable?
- Is the wiring neat, correct, and to the wiring diagram?
- Is the unit properly grounded and protected (fused)?
- Is the thermostat correctly wired, level, and in a good location?
- Are all access panels in place and secure?

Check Airflow

The Control Board

The control board regulates airflow selection and features LED indicators that display operating mode, humidity control, and airflow CFM. The red LED flashes once for each 100 CFM. For example, if the operating CFM is 1200, the CFM LED will flash 12 times, then pause before repeating the 12-flash pattern.

Thermostat signals for emergency heat (EM), auxiliary heat (W1), reversing valve (O), compressor (Y1), and blower (G) are all indicated by lit LED's on this board.

This model is designed for use with heat pumps as well as air conditioning systems. The control board needs to sense a signal on the "O" thermostat wire in order to use cooling delay timing. For a straight air conditioning system, connect the "O" wire to the 24 volt "R" wire.

WARNING



Electrical Shock Hazard

Disconnect all power supplies before servicing.

Replace all parts and panels before operating.


Failure to do so can result in death or electrical shock.

1. Disconnect all power supplies.
2. Locate the control board in the blower control box.

3. Set the HEAT and COOL taps by moving the board jumpers to the A, B, C, or D positions (see Motor Board Taps and Dehumidify Resistor) based on the information found in the Application Table.

NOTE: If using a humidistat, the dehumidify resistor located on the bottom right of the control board must be removed to enable it. See Control Board Taps and Dehumidify Resistor. The HUM terminal on the board must be connected to the Normally Closed contact of the humidistat so that the board senses an open circuit on high humidity. If a humidistat is used, the dehumidify LED (see D1 below) will light when the humidistat opens and the motor runs at reduced airflow.

Control Board Taps and Dehumidify Resistor.



1. Dehumidify LED
2. Dehumidify resistor

4. If desired, adjust ADJUST tap from NORM: (+) will increase airflow by 10% or (-) will decrease airflow by 12%
5. Reconnect all power supplies.

Application Table

The versatility of the variable speed motor enables the electric furnace to tailor its performance to the different modes of operation encountered in heating and cooling. All variable speed electric furnaces are capable of operation at more than one nominal airflow rate. The operation of a variable speed electric furnace blower at different airflow rates is determined by the control board taps and the thermostat. See the Application Table. Before beginning the setup, become familiar with the information found in the Application Table. The data in the application table is categorized by model size and mode of operation. Use the information provided to determine the CFM taps needed for cooling and heating.

Application Table

Model	Mode	Thermostat Terminals X = Energized Terminal						Control Board Taps							
								Cool				Heat			
		HUM	EM	W1	O	Y2/Y1	G	A	B	C	D	A	B	C	D
								CFM	CFM	CFM	CFM	CFM	CFM	CFM	CFM
WEFV08S -1A	Cont. Blower						X	500	400	375	375				
	Cooling	**			X	X		1000	800	700	600				
	Heating					X		1000	800	700	600				
	Aux. Heat***			X		X		***	***	***	***	1000	800	700	600*
	Emer. Heat***		X	X				***	***	***	***	1000	800	700	600*
WEFV12S-1A	Cont. Blower						X	600	500	400	350				
	Cooling	**			X	X		1200	1000	800	600				
	Heating					X		1200	1000	800	600				
	Aux. Heat***			X		X		***	***	***	***	1200	1100*	1100*	1100*
	Emer. Heat***		X	X				***	***	***	***	1200	1100*	1100*	1100*
WEFV14M-1A	Cont. Blower						X	750	700	600	500				
	Cooling	**			X	X		1500	1400	1200	1000				
	Heating					X		1500	1400	1200	1000				
	Aux. Heat***			X		X		***	***	***	***	1500	1400	1200*	1200*
	Emer. Heat***		X	X				***	***	***	***	1500	1400	1200*	1200*
WEFV16M-1A	Cont. Blower						X	900	800	750	700				
	Cooling	**			X	X		1800	1600	1500	1400				
	Heating					X		1800	1600	1500	1400				
	Aux. Heat***			X		X		***	***	***	***	1800	1700	1600*	1500*
	Emer. Heat***		X	X				***	***	***	***	1800	1700	1600*	1500*
WEFV20L-1A	Cont. Blower						X	1000	950	900	800				
	Cooling	**			X	X		2000	1900	1800	1600				
	Heating					X		2000	1900	1800	1600				
	Aux. Heat***			X		X		***	***	***	***	2000	1800	1700	1700
	Emer. Heat***		X	X				***	***	***	***	2000	1800	1700	1700

*This CFM is not approved for use with highest kW heater size.

**Humidistat will reduce cooling airflow by 10% in high humidity.

***Airflow is the greater of the COOL and HEAT values when both electric heat and heat pump are operating.

NOTES:

Adjust tap (+) will increase airflow by 10%, while tap (-) will decrease airflow by 12%.

Adjust tap test will cause the motor to run at 70% of full airflow. Use this for troubleshooting only.

At the start of a call for cooling there is a short run at 82% of airflow for 7.5 minutes.

At the end of a call for cooling there is a blower delay of 1 minute.

SEQUENCE OF OPERATION

Cooling (cooling only or heat pump)

When the thermostat calls for cooling, the circuit between R and G is completed, and the blower relay is energized. The Normally Open contacts close, causing the indoor blower motor to operate. The circuit between R and Y is also completed; this circuit closes the contactor in the outdoor unit starting the compressor and outdoor fan motor. Circuit R and O energizes the reversing valve, switching it to the cooling position. (The reversing valve remains energized as long as selector switch is in the COOL position.)

Heating (electric heat only)

When the thermostat calls for heat, the circuit between R and W is completed, and the heater sequencer is energized. A time delay follows before the heating elements and the indoor blower motor come on. Units with a second heat sequencer can be connected with the first sequencer to W on the thermostat sub-base or connected to a second stage on the sub-base.

Heating (heat pump)

When the thermostat calls for heat, the circuits between R and Y and R and G are completed. Circuit R-Y energizes the contactor starting the outdoor fan motor and the compressor. Circuit R and G energizes the blower relay starting the indoor blower motor.

If the room temperature should continue to fall, the circuit between R and W 1 is completed by the second stage heat room thermostat. Circuit R-W 1 energizes a heat sequencer. The completed circuit will energize supplemental electric heat (if applicable). Units with a second heater sequencer can be connected with the first sequencer to W 1 on the thermostat or connected to a second heating stage W 2 on the thermostat sub-base.

Auxiliary Heat (heat pump)

When the thermostat functions to call for auxiliary heat, the heat pump is turned off. Place a jumper wire between Terminals W2 and E on the thermostat terminal connections. See Heat Pump Application wiring diagram. This will allow the indoor blower to cycle on and off with the electric heat when the fan switch is in the AUTO position.

Variable Speed Features

The EFV electric furnace is equipped with a variable speed motor and will deliver a constant airflow within a wide range of external static pressures. The variable speed blower offers the following comfort features:

Soft Start

When called into operation, the variable speed motor will slowly ramp up to normal operating speed. This eliminates the noise and discomfort that results caused by the initial blast of air encountered with standard electric furnaces. It can take up to 7.5 minutes to reach normal operating speed.

Continuous Blower Operation

The comfort level of the living space can be enhanced when using this feature by allowing continuous circulation of air in between calls for cooling or heating. The circulation of air between calls for cooling or heating occurs at 50% of the normal airflow rate (350 CFM minimum).

Reduced Airflow Operation

For situations where humidity control is a problem, the variable speed motor can be enabled to operate at a 10% reduction in the normal airflow rate under the control of a humidistat. This can be achieved by connecting to a standard humidity control that is normally closed and opens on humidity rise.

ELECTRIC FURNACE MAINTENANCE

IMPORTANT: Do not operate system without a filter. A filter is required to protect the coil, blower, and internal parts from excessive dirt and dust.

- Inspect air filters at least once a month and replace or clean as required. Dirty filters are the most common cause of inadequate heating or cooling performance.
- Replace disposable filters. Cleanable filters can be cleaned by soaking in mild detergent and rinsing with cold water.
- Install new/clean filters with the arrows on the side pointing in the direction of airflow.
- Never replace a cleanable (high velocity) filter with a disposable (low velocity) filter unless return air system is properly sized for it.

ASSISTANCE OR SERVICE

If you need further assistance, you can write to the below address with any questions or concerns:

Whirlpool® Home Cooling and Heating
7901 S.W. 6th Court
Plantation, Florida 33324

Please include a daytime phone number in your correspondence.

Accessories

To order accessories ask for the appropriate part number listed below or contact your Whirlpool® Home Cooling and Heating dealer.

AEFFLTS-1	Filter Kit for 17.5 in. x 22.5 in. cabinets
AEFFLTM492-1	Filter Kit for 22 in. x 21.5 in. cabinets
AEFFLTL493-1	Filter Kit for 22 in. x 26 in. cabinets

Electric Heat Kits

Refer to the Accessory Kit Label on the front panel of the electric furnace for electric heat kit options and applications.

Limited Warranty

September 2002

This warranty gives you specific legal rights and you may have other rights which vary from state/province to state/province. This warranty applies to U.S. and Canada only.

Warrantor: Allied Air Enterprises Inc., 355 Millennium Dr., Orangeburg, SC 29115

Products are available under the following brand names: Whirlpool, Whirlpool Gold

IF SOMETHING GOES WRONG, CONTACT THE WHIRLPOOL HOME COOLING & HEATING DEALER FROM WHOM YOU PURCHASED YOUR EQUIPMENT. IN MOST CASES, YOUR DEALER WILL BE ABLE TO CORRECT THE PROBLEM, BUT IF HE/SHE IS NOT ABLE TO DO SO, YOU SHOULD CONTACT TRADEWINDS DISTRIBUTING DIRECTLY IN WRITING AT THE FOLLOWING ADDRESS:

**Whirlpool® Home Cooling and Heating
7901 S.W. 6th Court
Plantation, Florida 33324**

General Warranty

Subject to the limitations stated in this warranty, we warrant the covered equipment for residential use, when installed, operated and maintained according to the manufacturer's instructions, to be free of defects in workmanship or materials for a period of 5 years (1 year for commercial use) from the time of initial installation. We will replace any defective component without cost or expense to you except for the costs of diagnosis, delivery and labor for removing, servicing and/or replacing the parts or unit.

Warranty Begins

The warranty period begins when the installation is complete and the product is ready to operate. You must be able to verify this date whenever a warranty claim is made. Original bill of sale, installer's invoice or other similar document will suffice. If the beginning date cannot be verified, we will consider warranty coverage to begin 6 months after the date the product was shipped from our factory.

Limitations on Implied Warranties

Implied warranties of merchantability or, to the extent applicable, fitness for a particular purpose are excluded to the extent legally permissible and are in any event limited to 5 years, or the shortest period allowed by law. Some states/provinces do not allow limitations or exclusions on how long an implied warranty of merchantability or fitness lasts, so the above limitations or exclusions may not apply to you.

Only Warranty

This written Limited Warranty is the only warranty made by the warrantor; this warranty is in lieu of and excludes all other warranties by the warrantor, express or implied. The warrantor does not authorize any person to provide on its behalf any other warranty or to assume for it any further obligation in connection with the warranted product.

What is NOT Covered by Any Warranty

1. Cabinets or cabinet pieces.
2. Normal maintenance items such as filters, fan belts, fuses or other consumable items.
3. Damage caused by misuse, failure to maintain properly, accidents or acts of God.
4. External wiring, piping, venting or attachment of accessory products not integral to our product, including without limitation, humidifier, air cleaner, vent damper, thermostat or other mechanical devices not manufactured by the warrantor.
5. Products that have been operated in a corrosive atmosphere or otherwise in contact with corrosive materials where a concentration of acids, halogenated hydrocarbons or other corrosive elements such as urine, salt, etc. causes deterioration to metal surfaces or integral components. NOTE: Operation in a corrosive atmosphere is considered misuse and voids this warranty.
6. Products that have NOT been installed, used and maintained in accordance with our published installation instructions, applicable local, state/provincial or national codes, and/or ACCA published standards.
7. Products that have NOT been installed by competent, qualified installers.
8. Products that have been moved from their original place of installation.

Warranty on Replacement Components

Any replacement product or component furnished by us will assume the remaining (unused) portion of the Limited Warranty.

Consequential Damages

The warrantor shall not be responsible for any accidental consequential damages caused by any defect in the product. Some state/provinces do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This product must be installed, used and cared for in accordance with the instruction manual. You are responsible for required periodic maintenance or service, such as changing or cleaning of air filters and lubrication or cleaning of components. **Failure to properly install, operate or maintain your unit voids this warranty.**

Keep this book and your sales slip together for future reference. You must provide proof of purchase or installation date for in-warranty service.

Write down the following information about your furnace to better help you obtain assistance or service if you ever need it. You will need to know the complete model and serial number. You can find this information on the front panel.

Dealer name _____

Address _____

Phone number _____

Model number _____

Serial number _____

Installation date _____

