CLICK ANYWHERE on THIS PAGE to RETURN to WATER SOFTENERS at InspectApedia.com



INSTALLATION, OPERATION, AND MAINTENANCE MANUAL

FMR 60M–450M TWIN ALTERNATING METERED 1-1/2" SXT SERIES COMMERCIAL WATER CONDITIONERS

COMPLETE FOR FUTURE REFERENCE:

MODEL NO:

SERIAL NO:

DATE INSTALLED:

DEALER:



FMR 60M-450M SXT 1-1/2" TWIN ALTERNATING METERED

Please Circle and/or Fill in the Appropriate Data for Future Reference:

Softener Model:	FMR
System Size:	Twin Alternating - Twin Tank
Configuration:	Timeclock/Electromechanical Metered/SXT Metered/XT Metered
BW/Regen Time:	AM/PM or OFF

Additional Notes: _____

IMPORTANT PLEASE READ:

- · Warranty of this product extends to manufacturing defects.
- The information, specifications and illustrations in this manual are based on the latest information available at the time of printing. The manufacturer reserves the right to make changes at any time without notice.
- This product should be installed by a plumbing professional on potable water systems only.
- This product must be installed in compliance with all local and state and municipal plumbing and electrical codes. Permits may be required at the time of installation.
- If operating pressure exceeds 100 psi a pressure reducing valve must be installed. If operating pressure drops below 30 psi a booster pump must be installed.
- Do not install the unit where temperatures may drop below 32°F or rise above 100°F.
- A prefilter should be used on installations in which free solids are present.
- A constant voltage of 120V/60Hz (unless otherwise specified) must be supplied to the controller to maintain proper function.
- Union or flange fittings are recommended at the control valve's inlet, outlet, and drain connections
- If distance of drain line is over a 10 ft. vertical or 25 ft. horizontal run, increase drain line one pipe size over that provided on the control valve.
- Do not make a direct connection to the drain. Provide an air gap of at least four times the diameter of the pipe to conform to sanitation codes and to permit observation of the flow.



FMR 60M-450M SXT 1-1/2" TWIN ALTERNATING METERED

TABLE OF CONTENTS

SYSTEM INFORMATION

Product Warranty	1
General Arrangement Drawings	2
Dimensional Data	3
Specification Table	4

INSTALLATION

General Information	5
Loading Softener	6
Mounting Control Valve	7
Piping Installation	7

OPERATION

Start-Up Procedure	7
SXT Timer Features	9
Controller Operation	10
Aaster Programming Mode Chart	12
Aaster Programming Mode	13
Jser Programming Mode	18
Diagnostic Programming Mode	19
Flow Diagrams	21
Viring Diagram	24

MAINTENANCE

SXT Timer Assembly	25
Powerhead Assembly	
9500 Control Valve Assembly	
Second Tank Adapter Assembly	
Meter Assemblies	31
Brine Tank Assemblies	
Service Assemblies	
Troubleshooting	

CleaverBrooks[®]

COMMERCIAL AND INDUSTRIAL PRODUCT WARRANTY

Manufacturer warrants all commercial and industrial water treatment products manufactured and/or distributed by it to be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. The fiberglass mineral tank(s) alone have a warranty for a period of five (5) year from the date of shipment. If within that period any products shall be proven to Manufacturer's satisfaction to be defective, those products will be replaced or the price refunded at Manufacturer's option.

Manufacturer's obligations or nonperformance, defective, or any damage caused by its products or their use, and buyer's exclusive remedy therefore, shall be limited to product replacement or refund and shall be conditioned upon Manufacturer's receiving written notice together with a demand for such replacement or refund:

The foregoing warranty is exclusive and in lieu of all other expressed implied warranty (except of title) including but not limited to implied warranty of merchantability and fitness for particular purpose.

Manufacturer will not be subject to and disclaims the following:

- 1. Any other obligations or liabilities arising out of breach of contract or out of warranty.
- Any obligations whatsoever arising from tort claims (including negligence and strict liability or arising under other theories of law with respect to products sold or services rendered by Manufacturer. or any undertakings, acts, or omissions relating thereto.
- 3. All consequential, incidental, and contingent damages. Labor charges, charge backs or handling charges are excluded from Manufacturer's warranty provisions.

COMMERCIAL AND INDUSTRIAL WATER SOFTENER GUARANTEE

Under normal operating conditions:

- 1. The softener effluent shall be zero soft as determined by a soap test.
- 2. The loss of softening resin through attrition during the first three (3) years shall not exceed 3% per year.
- 3. The softening resin shall not be washed out of the system during backwash.
- 4. The color and turbidity of the softener effluent shall not be greater than the incoming water. Any mechanical equipment proving defective in workmanship or material within one year after installation or eighteen (18) months after shipment, whichever comes first, shall be replaced FOB factory.

CleaverBrooks[®]

Ø

FMR 60M-450M SXT 1-1/2" TWIN ALTERNATING METERED SYSTEM INFORMATION



2





DIMENSION CHART

		TANK	SIZE		WIDTH		
MODEL	(Inches)	SOFTENER (Inches)	NER BRINE (Inches) es) (Inches)		(Inches)	(Inches)	
60	1-1/2	12x52	18x40	36	18	65	
90	1-1/2	14x65	18x40	38	18	78	
120	1-1/2	16x65	24x40	46	25	78	
150	1-1/2	18x65	24x50	48	24	79	
210	1-1/2	21x62	24x50	51	24	76	
240	1-1/2	24x72	24x50	54	24	86	
300	1-1/2	24x72	24x50	54	24	86	
450	1-1/2	30x72	30x50	66	30	93	
*Leave a minimum 2	4 inch clearance to the	height of the unit for lo	ading media.				

Dimensions are for general arrangement use only.

CleaverBrooks

FMR 60M-450M SXT 1-1/2" TWIN ALTERNATING METERED SYSTEM INFORMATION

SPECIFICATION CHART

Ļ	ų	MODEL	60	90	120	150	180	210	240	270	300	450
10		VALVE SIZE (IN)	1-1/2	1-1/2	1-1/2	1-1/2	1-1/2	1-1/2	1-1/2	1-1/2	1-1/2	1-1/2
110/		MAX CAPACITY (KILOGRAINS)	60	90	120	150	180	210	240	270	300	450
ة 	0	MIN CAPACITY (KILOGRAINS)	40	60	80	100	120	140	160	180	200	300
=	E	SERVICE - CONTINUOUS (GPM)	28	31	34	38	41	39	43	42	41	45
	19	SERVICE - PEAK (GPM)	39	42	46	50	54	52	57	55	55	62
	L K	BACKWASH & FAST FLUSH (GPM)	3.5	5	6	8	12	12	15	15	15	25
		BRINE DRAW & RINSE (GPM)	1	1	1.2	1.2	1.5	1.5	3.2	3.2	3.2	3.5
ī	Ē	BRINE TANK REFILL (GPM)	1	1	1	2	2	2	2.2	2.2	2.2	5
		BACKWASH & FAST FLUSH (MIN)	10	10	10	10	10	10	10	10	10	10
ER	INGS	BRINE DRAW & RINSE (MIN)	60	60	60	60	60	60	60	60	60	60
TIN	SETT	FAST FLUSH (MIN)	10	10	10	10	10	10	10	10	10	10
		BRINE TANK REFILL (MIN)	10	16	20	14	18	18	20	22	26	16
~		SIZE (IN)	12x52	14x65	16x65	18x65	21x62	21x62	24x72	24x72	24x72	30x72
ENER	MK	GRAVEL (LBS)	0	30	35	40	80	80	120	120	120	225
SOFT	TA	RESIN (FT ³)	2	3	4	5	6	7	8	9	10	15
		FREEBOARD (IN)	16	21	21	24	23	18	30	25	21	22
	F	TANK SIZE	18x40	18x40	24x40	24x40	24x40	24x50	24x50	24x50	24x50	30x48
	MEN	MAX SALT STORAGE (LBS)	320	270	550	500	500	600	550	500	450	590
	QUIF	INJECTOR CODE	3	3	4	3C	4C	4C	5C	5C	5C	6C
S	ш	INJECTOR COLOR	YEL	YEL	GRN	YEL	GRN	GRN	WHT	WHT	WHT	RED
TEM	5	SALT DOSAGE- MAX (LBS)	30	45	60	75	90	105	120	135	150	225
SYS	SA	SALT DOSAGE- MIN (LBS)	10	16	20	14	16	18	20	22	26	16
RINE	Ξ	REFILL TIME - MAX (MIN)	10	16	19	17	6	6	4	3	2	3
	REF	REFILL TIME - MIN (MIN)	4	6	8	6	6	8	8	10	10	6
	SEN SEN	REGEN PER SALT REFILL-MAX	10	6	9	7	6	6	4	3	2	3
	REG	REGEN PER SALT REFILL-MIN	26	15	23	17	17	17	10	8	6	7
	RE	GENERATION WASTE VOLUME (GAL)	126	156	188	228	272	366	520	536	544	860

SPECIFICATION NOTES

Maximum salting is 15 pounds of salt per cubic foot of resin. Minimum salting is 6 pounds of salt per cubic foot of resin.

The regeneration timer is setup for maximum salting at the factory. The Timer Settings are factory set and user adjustable.

On continuous flow rates pressure loss does not exceed 15 psig. On peak flow rates pressure loss does not exceed 30 psig.

Minimum operating pressure is 30 psi. Maximum operating pressure is 120 psi.

Standard units are designed to soften unheated water within the range of 35-100°F. Power requirements are 120 Volt, 60 Hertz, Single Phase, 2 amps non-interrupted.

Freeboard is the distance between the surface of the resin and the top of the tank. Salt specifications are pelletized or solar salt, 99% pure, containing less than 1% insolubles.

CleaverBrooks

INSTALLATION INSTRUCTIONS

GENERAL INFORMATION

- 1. Minimum operating pressure is 30 psi. If pressure less than 30 psi is encountered, a regulator must be installed
- **NOTE:** The control valve will not operate correctly if feeding into an atmospheric tank. A pressure control device must be added to the outlet to maintain the minimum pressure.
- 2. Maximum operating pressure is 120 psi. If pressure greater then 120 psi is encountered, a pressure regulator must be installed.
- 3. Power requirements are shown on a voltage sticker on the motor inside cover of the control valve. You can also tell by wire color on the motor: Black wires are 115 volt. Yellow wires are 220 volt. Blue wires are 24 volt.
- 4. Standard units are designed to soften unheated water not to exceed 100° F. Special valve assemblies are available to handle heated water supplies exceeding 100°F. Consult factory if applicable.
- 5. Each softener tank is shipped with distributor manifold and control valve preassembled. Take care when uncrating and erecting so that no items are damaged.
- 6. The distributor assembly has been shipped inside the fiberglass mineral tank. Check to make sure that there is no damage to the riser pipe, baskets, laterals, or hub prior to loading media.

LAYOUT REQUIREMENTS

- Select a location that is accessible and near a floor drain that has adequate carrying capacity to handle the softener regeneration flow. See specification table for the flow rate. Allow a minimum of 24" above the tank for loading media.
- 2. Erect each the softener tanks on a concrete or other firm foundation and level.
- **NOTE:** If the system is skid mounted, it will be prepiped and preloaded at the factory. Skip the following instructions and go to the section "Installation of Connection Piping".
- 3. Position the brine tank according to the illustration and supplementary brine tank information. Keep the brine tank as close as possible to the softener tanks.

NOTE: The distance between the softener and brine tanks will affect the brine injector performance, as the distance increases the injector performance decreases. This may cause an inadequate regeneration. Maximum recommended distance is 5 ft.

4. A grounded electric receptacle is required for the control valve transformer.

CleaverBrooks®

INSTALLATION INSTRUCTIONS

LOADING TANK

- **NOTE:** If the system is skid mounted, it will be prepiped and preloaded at the factory. Skip the following instructions and go to the section of "Installation of connection piping".
- 1. On Models MAT-15, 30, 45, and 60 the softening media has been pre-loaded at the factory. Skip this section and go to "Mounting Control Valve Assembly".
- 2. Fill a tank approximately 1/3 full of water using a hose, bucket, etc. Plug the PVC distributor manifold pipe using a plastic cap, cork, rag, etc. No gravel or resin should go into this distributor manifold pipe.
- 3. Verify the distributor manifold is center in the tank with the distributor resting on the bottom of the tank. Verify the riser pipe is still plugged.
- **NOTE:** Reference the specification table in the front of this manual for the correct quantities of gravel and resin. These quantities are for each tank. Make sure you have the required amounts on site before you begin.
- 4. With care not to damage any lateral, pour in the gravel provided for each tank through the top opening in the tank and level out evenly. This will cover the distributor assembly.

NOTE: Wetting the gravel in the bags before loading will eliminate the normal amount of dust.

- 5. When gravel is loaded and leveling is completed, proceed as follows:
- 6. With the distributor riser pipe still plugged, add the proper amount of resin supplied for each tank through the top opening in the tank.

CAUTION: The softener resin is very slippery. Take care when stepping on any spilled resin. Remove spilled resin from standing surface immediately.

- 7. When loading is complete, remove plastic cap, cork, or rag that was used to plug the distributor riser pipe. Be careful not to let any foreign debris fall into the pipe. The result could be damage to system.
- 8. Repeat instruction steps 1-7 for the second softener tank.

MOUNTING WATER METER ASSEMBLY (MAY BE FACTORY CONNECTED)

- 1. Locate the meter. The water meter has a flow arrow stamped on it. The flow arrow on the meter should be pointing away from the control valve.
- 2. Attach the meter to the control valve's outlet water connection.3. Interconnect meter cable between the control valve timer and water meter dome.

MOUNT CONTROL VALVE ASSEMBLY

- 1. Verify that the distributor riser pipe is not plugged.
- 2. Lubricate the distributor o'ring on the bottom of the control valve with silicone.
- 3. Insert disperser in threaded base of control valve. The threaded base has a groove machined into the inside of the threaded part of the base to allow for the installation of this disperser.
- 4. Screw control valve into top opening of tank making sure the distributor riser pipe slides easily through the distributor o'ring. Care must be taken not to "nick" this o-ring as hard water leakage could result.
- 5. Tighten down the control valve to ensure positive o-ring seal at top of tank.
- 6. Repeat instruction steps 1-5 for each softener tank (if applicable).

CleaverBrooks°

INSTALLATION OF CONNECTION PIPING

NOTES:

- · Use thread sealing tape on all threaded piping connections.
- Install the piping conforming to federal, provincial, and local codes.
- Unions or flanges are recommended at the control valve's inlet and outlet connections. To enhance the monitoring
 of the system's performance sample valves and pressure gauges can be installed at the inlet and outlet piping of
 the softening unit (not provided).
- If distance of drain line is over 10 ft. vertical or 25 ft. horizontal run, increase drain line one pipe size over that provided on the control valve.
- Do not make a direct connection to the drain. Provide an air gap of at least four times the diameter of the pipe to conform to sanitation codes and to permit observation of the flow.
- It is not recommended that an overhead or a long horizontal drain run be used. The increase of backpressure will cause problems when drawing brine.

Caution: All piping must be properly supported. The tank and valve assemblies are not meant to support the connecting piping.

- 1. Install piping as shown on installation diagram. It is recommended that unions be installed before the inlet and outlet valves to facilitate service of unit. Be sure piping is free of thread chips and other foreign matter. The connecting piping should be the same size or larger then the service inlet and outlet of the control valve.
- 2. Verify that the flow arrow stamped on the drain flow controller is pointing away from the control valve. See installation diagram or valve manual for the location. Install a drain line from backwash control assembly to an appropriate drain using a minimum of elbows. Install a union near the backwash control to facilitate cleaning. Do not install a valve on the drain line.
- 3. Interconnect the brine line tubing between the control valve and the brine tank. Verify that the brine line tubing is not kinked or restricted
- 4. Run flexible tubing (not provided) from the brine tank's over flow fitting to an appropriate, nonelevated, open drain.

START-UP

- 1. Again, make sure all plumbing is complete and tight including drain line and brine line. Make sure all electrical connections are complete per wiring diagrams provided.
- 2. Using a bucket or hose, fill brine tank with water to 2" above salt platform. Do not add salt at this time.
- 3. Make sure inlet and outlet isolation valves are closed. Turn on power to the system.

NOTE: Start up only one (1) tank at a time.

The softening cycle steps are as follows:

- Service
- Step 1 (Backwash)
- Step 2 (Brine Draw/ Slow Rinse)
- Step 3 (Fast Rinse)
- Step 4 (Brine Tank Refill)
- Return to Service



START-UP (continued)

REGENERATION STEPS

- **Backwash:** The cycle duration is factory set at 10 minutes for clean feed water applications. Increase time duration to 15 minutes when turbidity is present in the feed water.
- Brine Draw/Rinse: The cycle duration is factory is set at 60 minutes to assure the required amount of brine is introduced and rinsed from the resin. Increase time duration when the injector feed pressure is below 40 psi.
- **Fast Flush:** The cycle duration is factory set at 10 minutes to rinse chlorides from the resin prior to the softener is placed online. Increase time duration to 15 minutes if traces of chlorides are present in the service outlet water.
- Brine Tank Refill: The cycle duration is factory set at the maximum salt to achieve maximum softener capacity. The published minimum salt can be programmed to reduce salt consumption by 50% and reduced softening capacity by 30%.
- **Cycle End:** The cycle duration is factory set at 4 minutes. Its purpose is to identify the end of regeneration and advance the softener control valve to the Standby position.
- **Note:** Brine Draw / Slow Rinse step is actually two events. The brine is suctioned from the brine tank until the level falls to the bottom of the brine valve. An air check in the valve will close once the brine is to low. This is the end for the Brine Draw step and should last about twenty (20) minutes. The rest of the time in Step 2 is Slow Rinse.
- 4. Locate the extra regeneration button 🔅 on the front side of the timer. Press the button for 5 seconds. The softener control valve will advance to Backwash position. Be patient this will take several minutes.
- 5. Remove electrical power from unit, and then slowly open inlet water valve approximately half open. Water will begin to fill through bottom distributor into tank. When tank is full, water will begin to flow out of drain line. Slowly open inlet valve until full open. Allow water to flow from drain line for approximately 15 minutes.Warning: Monitor this drain water flow carefully. There is a problem if you see softener resin in the drain water. Turn off inlet water immediately and then consult factory.
- 6. Restore electrical power to unit. Advance the control valve to Brine Draw / Slow Rinse position, using the same method as step 5. Make sure unit draws water from brine tank. There should also be reduced flow at the drain line.
- 7. Advance the control valve to the Fast Rinse position. Remove electrical power to the unit. Let water run to drain position for approximately 5 minutes or until water runs clear.
- 8. Restore electrical power to unit. Advance the control valve to Brine Refill position. Water should begin to refill brine tank. Allow the brine tank to refill until water in salt tank is again 2" above the salt platform. There should be no flow to drain in this valve position.
- 9. Advance control valve to Service position. Brine tank refill should stop. Open outlet valve and run water at the nearest cold water faucet to the water softener system for
- 10. Repeat instruction steps 1-10 for each softener tank.
- 11. Add salt to the brine tank. **Use pelletized or solid salt**, 99.0 99.8% pure salt containing less than 0.5% insoluble.
- 12. Use the test kit provided to check water for softness. Check the water hardness daily the first week in order to establish how often the softener should be regenerated. approximately 5 minutes.



TIMER FEATURES



FEATURES OF THE SXT:

- Power backup that continues to keep time and the passage of days for a minimum of 48 hours in the event of power failure. During a power outage, the control goes into a power-saving mode. It does not monitor water usage during a power failure, but it does store the volume remaining at the time of power failure.
- Settings for both valve (basic system) and control type (method used to trigger a regeneration).
- Day-of-the-Week controls.
- While in service, the display alternates between time of day, volume remaining or days to regeneration, and tank in service (twin tank systems only).
- The Flow Indicator flashes when outlet flow is detected.
- The Service Icon flashes if a regeneration cycle has been queued.
- A Regeneration can be triggered immediately by pressing the Extra Cycle button for five seconds.
- The Parameter Display displays the current Cycle Step (BW, BF, RR, etc) during regeneration, and the data display counts down the time remaining for that cycle step. While the valve is transferring to a new cycle step, the display will flash. The parameter display will identify the destination cycle step (BW, BF, RR, etc) and the data display will read "----". Once the valve reaches the cycle step, the display will stop flashing and the data display will change to the time remaining. During regeneration, the user can force the control to advance to the next cycle step immediately by pressing the extra cycle button.



TIMER FEATURES

SETTING THE TIME OF DAY

- 1. Press and hold either the Up or Down buttons until the programming icon replaces the service icon and the parameter display reads TD.
- 2. Adjust the displayed time with the Up and Down buttons. When the desired time is set, press the Extra Cycle button to resume normal operation. The unit will also return to normal operation after 5 seconds if no buttons are pressed.



ENTERING MASTER PROGRAMMING MODE

Set the Time Of Day display to 12:01 P.M. Press the Extra Cycle button (to exit Setting Time of Day mode). Then press and hold the Up and Down buttons together until the programming icon replaces the service icon and the Display Format screen appears.

EXITING MASTER PROGRAMMING MODE

Press the Extra Cycle button to accept the displayed settings and cycle to the next parameter. Press the Extra Cycle button at the last parameter to save all settings and return to normal operation. The control will automatically disregard any programming changes and return to normal operation if it is left in Master Programming mode for 5 minutes without any keypad input.

RESETS

- **Soft Reset:** Press and hold the Extra Cycle and Down buttons for 25 seconds while in normal Service mode. This resets all parameters to the system default values, except the volume remaining in meter immediate or meter delayed systems and days since regeneration in the time clock system.
- **Master Reset:** Hold the Extra Cycle button while powering up the unit. This resets all of the parameters in the unit. Check and verify the choices selected in Master Programming Mode.

CONTROLLER OPERATION

METER IMMEDIATE CONTROL

A meter immediate control measures water usage and regenerates the system as soon as the calculated system capacity is depleted. The control calculates the system capacity by dividing the unit capacity (typically expressed in grains/unit volume) by the feedwater hardness and subtracting the reserve. Meter Immediate systems generally do not use a reserve volume. However, in twin tank systems with soft-water regeneration, the reserve capacity should be set to the volume of water used during regeneration to prevent hard water break-through. A Meter Immediate control will also start a regeneration cycle at the programmed regeneration time if a number of days equal to the regeneration day override pass before water usage depletes the calculated system capacity.

METER DELAYED CONTROL

A Meter Delayed Control measures water usage and regenerates the system at the programmed regeneration time after the calculated system capacity is depleted. As with Meter Immediate systems, the control calculates the system capacity by dividing the unit capacity by the feedwater hardness and subtracting the reserve. The reserve should be set to insure that the system delivers treated water between the time the system capacity is depleted and the actual regeneration time. A Meter Delayed control will also start a regeneration cycle at the programmed regeneration time if a number of days equal to the regeneration day override pass before water usage depletes the calculated system capacity.

METER DELAYED CONTROL

A Time Clock Delayed Control regenerates the system on a timed interval. The control will initiate a regeneration cycle at the programmed regeneration time when the number of days since the last regeneration equals the regeneration day override value.



CONTROLLER OPERATION (continued)

DAY OF THE WEEK CONTROL

This control regenerates the system on a weekly schedule. The schedule is defined in Master Programming by setting each day to either "off" or "on." The control will initiates a regeneration cycle on days that have been set to "on" at the specified regeneration time.

CONTROL OPERATION DURING REGENERATION

During regeneration, the control displays a special regeneration display. In this display, the control shows the current regeneration step number the valve is advancing to, or has reached, and the time remaining in that step. The step number that displays flashes until the valve completes driving to this regeneration step position. Once all regeneration steps are complete the valve returns to service and resumes normal operation.

Pressing the Extra Cycle button during a regeneration cycle immediately advances the valve to the next cycle step position and resumes normal step timing.

CONTROL OPERATION DURING PROGRAMMING

The control only enters the Program Mode with the valve in service. While in the Program Mode, the control continues to operate normally monitoring water usage and keeping all displays up to date. Control programming is stored in memory permanently, eliminating the need for battery backup power.

MANUALLY INITIATING A REGENERATION

- 1. When timer is in service, press the Extra Cycle button for 5 seconds on the main screen.
- 2. The timer advances to Regeneration Cycle Step #1 (backwash), and begins programmed time count down.
- 3. Press the Extra Cycle button once to advance valve to Regeneration Cycle Step #2 (brine draw & slow rinse).
- 4. Press the Extra Cycle button once to advance valve to Regeneration Cycle Step #3 (rapid rinse).
- 5. Press the Extra Cycle button once to advance valve to Regeneration Cycle Step #4 (brine refill).
- 6. Press the Extra Cycle button once more to advance the valve back to in service.

NOTE: If the unit is a filter or upflow, the cycle step order may change.

NOTE: A queued regeneration can be initiated by pressing the Extra Cycle button. To clear a queued regeneration, press the Extra Cycle button again to cancel. If regeneration occurs for any reason prior to the delayed regeneration time, the manual regeneration request shall be cleared.

TIMER FEATURES

CONTROL OPERATION DURING A POWER FAILURE

The SXT includes integral power backup. In the event of power failure, the control shifts into a power-saving mode. The control stops monitoring water usage, and the display and motor shut down, but it continues to keep track of the time and day for a minimum of 48 hours.

The system configuration settings are stored in a non-volatile memory and are stored indefinitely with or without line power. The Time of Day flashes when there has been a power failure. Press any button to stop the Time of Day from flashing.

If power fails while the unit is in regeneration, the control will save the current valve position before it shuts down. When power is restored, the control will resume the regeneration cycle from the point where power failed. Note that if power fails during a regeneration cycle, the valve will remain in it's current position until power is restored. The valve system should include all required safety components to prevent overflows resulting from a power failure during regeneration.

The control will not start a new regeneration cycle without line power. If the valve misses a scheduled regeneration due to a power failure, it will queue a regeneration. Once power is restored, the control will initiate a regeneration cycle the next time that the Time of Day equals the programmed regeneration time. Typically, this means that the valve will regenerate one day after it was originally scheduled. If the treated water output is important and power interruptions are expected, the system should be setup with a sufficient reserve capacity to compensate for regeneration delays.



MASTER PROGRAMMING MODE CHART

Master Programming Options				
Abbreviation	Parameter	Parameter Option Options Abbreviation		
		GAL	Gallons	
DF	Display Format	Ltr	Liters	
		Cu	Cubic Meters	
		St1b	Standard Downflow/Upflow Single Backwash	
		St2b	Standard Downflow/Upflow Double Backwash	
VT	Valve Type	Fltr	Filter	
		UFbF	Upflow Brine First	
		Othr	Other	
		Fd	Meter (Flow) Delayed	
СТ	Control Type	FI	Meter (Flow) Immediate	
		tc	Time Clock	
		dAY	Day of Week	
	Number of Tanks	1	Single Tank System	
		2	Two Tank System	
		U1	Tank 1 in Service	
TS	Tank in Service	U2	Tank 2 in Service	
С	Unit Capacity		Unit Capacity (Grains)	
н	Feedwater Hardness		Hardness of Inlet Water	
RS	Reserve Selection	SF	Percentage Safety Factor	
			Fixed Reserve Capacity	
SF	Safety Factor		Percentage of the system capacity to be used as a reserve	
RC	Fixed Reserve Capacity		Fixed volume to be used as a reserve	
DO	Day Override		The system's day override setting	
RT	Regen Time		The time of day the system will regenerate	
BW, BD, RR, BF	Regen Cycle Step Times		The time duration for each regeneration step. Adjust- able from OFF and 0-199 minutes. NOTE: If "Othr" is chosen under "Valve Type", then R1, R2, R3, etc, will be displayed instead	
D1, D2, D3, D4, D5, D6, & D7	Day of Week Settings		Regeneration setting (On or OFF) for each day of the week on day-of-week systems	
CD	Current Day		The Current day of the week	
		t0.7	3/4" Turbine Meter	
		P0.7	3/4" Paddle Wheel Meter	
		t1.0	1" Turbine Meter	
FM	Flow Meter Type	P1.0	1" Paddle Wheel Meter	
		t1.5	1.5" Turbine Meter	
		P1.5	1.5" Paddle Wheel Meter	
		Gen	Generic or Other Meter	
К	Meter Pulse Setting		Meter pulses per gallon for generic/other flow meter	

NOTE:

Some items may not be shown depending on timer configuration.

The timer will discard any changes and exit Master Programming Mode if any button is not pressed for sixty seconds.

CAUTION: Before entering Master Programming, please contact your local professional water dealer.

Ø



MASTER PROGRAMMING MODE

ENTERING MASTER PROGRAMMING MODE

Set the Time Of Day display to 12:01 P.M. Press the Extra Cycle button (to exit Setting Time of Day mode). Then press and hold the Up and Down buttons together until the programming icon replaces the service icon and the Display Format screen appears.

When the Master Programming Mode is entered, all available option setting displays may be viewed and set as needed. Depending on current option settings, some parameters cannot be viewed or set.

1. Display Format (Display Code DF)

This is the first screen that appears when entering Master Programming Mode. The Display Format setting specifies the unit of measure that will be used for volume and how the control will display the Time of Day. This option setting is identified by "DF" in the upper left hand corner of the screen. There are three possible settings:

DISPLAY FORMAT SETTING	UNIT OF VOLUME	TIME OF DISPLAY
GAL	U.S. Gallons	12-hour AM/PM
Ltr	Liters	24-Hour
Cu	Cubic Meters	24-Hour



2. Valve Type (Display Code VT)

Press the Extra Cycle button. Use this display to set the Valve Type. The Valve Type setting specifies the type of cycle that the valve follows during regeneration. Note that some valve types require that the valve be built with specific subcomponents. Ensure the valve is configured properly before changing the Valve Type setting. This option setting is identified by "VT" in the upper left hand corner of the screen. There are 5 possible settings:

ABBREVIATION	PARAMETER
St1b	Standard Downflow/Upflow, Single Backwash
St2b	Standard Downflow/Upflow, Double Backwash
Fltr	Filter
UFbF	Upflow Brine First
Othr	Other



3. Control Type (Display Code CT)

Press the Extra Cycle button. Use this display to set the Control Type. This specifies how the control determines when to trigger a regeneration. For details on how the various options function, refer to the "Timer Operation" section of this service manual. This option setting is identified by "CT" in the upper left hand corner of the screen. There are four possible settings:

Meter Delayed:	Fd
Meter Immediate:	FI
Time Clock:	tc
Day of Week:	dAY





4. Number of Tanks (Display Code NT)

Press the Extra Cycle button. Use this display to set the Number of Tanks in your system. This option setting is identified by "NT" in the upper left hand corner of the screen. There are two possible settings:

Single Tank System: 1 Two-Tank System: 2



5. Tank in Service (Display Code TS)

Press the Extra Cycle button. Use this display to set whether tank one or tank two is in service. This option setting is identified by "TS" in the upper left hand corner of the screen. This parameter is only available if the number of tanks has been set to 2. There are two possible settings:

Tank One in Service: U1 Tank Two in Service: U2





6. Unit Capacity (Display Code C)

Press the Extra Cycle button. Use this display to set the Unit Capacity. This setting specifies the treatment capacity of the system media. Enter the capacity of the media bed in grains of hardness when configuring a softener system, and in the desired volume capacity when configuring a filter system. This option setting is identified by "C" in the upper left hand corner of the screen. The Unit Capacity parameter is only available if the control type has been set to one of the metered options. Use the Up and Down buttons to adjust the value as needed.



7. Feedwater Hardness (Display Code H)

Press the Extra Cycle button. Use this display to set the Feedwater Hardness. Enter the feedwater hardness in grains per unit volume for softener systems, or 1 for filter systems. This option setting is identified by "H" in the upper left hand corner of the screen. The feedwater hardness parameter is only available if the control type has been set to one of the metered options. Use the Up and Down buttons to adjust the value as needed.





8. Reserve Selection (Display Code RS)

Press the Extra Cycle button. Use this display to set the Safety Factor. Use this display to select the type of reserve to be used in your system. This setting is identified by "RS" in the upper left-hand corner of the screen. The reserve selection parameter is only available if the control type has been set to one of the metered options. There are two possible settings.



RS	SF - Safety Factor
rc	Fixed Reserve Capacity

9. Safety Factor (Display Code SF)

Press the Extra Cycle button. Use this display to set the Safety Factor. This setting specifies what percentage of the system capacity will be held as a reserve. Since this value is expressed as a percentage, any change to the unit capacity or feedwater hardness that changes the calculated system capacity will result in a corresponding change to the reserve volume. This option setting is identified by "SF" in the upper left hand corner of the screen. Use the Up and Down buttons to adjust the value from 0 to 50% as needed.



10. Fixed Reserve Capacity (Display Code RC)

Press the Extra Cycle button. Use this display to set the Reserve Capacity. This setting specifies a fixed volume that will be held as a reserve. The reserve capacity cannot be set to a value greater than one-half of the calculated system capacity. The reserve capacity is a fixed volume and does not change if the unit capacity or feedwater hardness are changed. This option setting is identified by "RC" in the upper left-hand corner of the screen. Use the Up and Down buttons to adjust the value as needed.



11. Day Override (Display Code DO)

Press the Extra Cycle button. Use this display to set the Day Override. This setting specifies the maximum number of days between regeneration cycles. If the system is set to a timer-type control, the day override setting determines how often the system will regenerate. A metered system will regenerate regardless of usage if the days since last regeneration cycle equal the day override setting. Setting the day override value to "OFF" disables this function. This option setting is identified by "DO" in the upper left hand corner of the screen. Use the Up and Down buttons to adjust the value as needed.





12. Regeneration Time (RT)

Press the Extra Cycle button. Use this display to set the Regeneration Time. This setting specifies the time of day the control will initiate a delayed, manually queued, or day override triggered regeneration. This option setting is identified by "RT" in the upper left hand corner of the screen. Use the Up and Down buttons to adjust the value as needed.



13. Regeneration Cycle Step Times

Press the Extra Cycle button. Use this display to set the Regeneration Cycle Step Times. The different regeneration cycles are listed in sequence based on the valve type selected for the system, and are identified by an abbreviation in the upper left-hand corner of the screen. The abbreviations used are listed below. If the system has been configured with the "OTHER" valve type, the regeneration cycles will be identified as R1, R2, R3, R4, R5, and R6. Each cycle step time can be set from 0 to 199 minutes, or "OFF." Setting a cycle step to "OFF" will disable all of the following steps. Setting a cycle step time to 0 will cause the control to skip that step during regeneration, but keeps the following steps available. Use the Up and Down buttons to adjust the value as needed. Press the Extra Cycle button to accept the current setting and move to the next parameter.



CYCLE STEP	ABBREVIATION
BD	Brine Draw
BF	Brine Fill
BW	Backwash
RR	Rapid Rinse
SV	Service

14. Day of Week Settings

Press the Extra Cycle button. Use this display to set the regeneration schedule for a system configured as a Day of Week control. The different days of the week are identified as D1, D2, D3, D4, D5, D6, and D7 in the upper lefthand corner of the display. Set the value to "ON" to schedule a regeneration or "OFF" to skip regeneration for each day. Use the Up and Down buttons to adjust the setting as needed. Press the Extra Cycle button to accept the setting and move to the next day. Note that the control requires at least one day to be set to "ON." If all 7 days are set to "OFF", the unit will return to Day One until one or more days are set to "ON."



15. Current Day (Display Code CD)

Press the Extra Cycle button. Use this display to set the current day on systems that have been configured as Day of Week controls. This setting is identified by "CD" in the upper left-hand corner of the screen. Use the Up and Down buttons to select from Day 1 through Day 7.





16. Flow Meter Type (Display Code FM)

Press the Extra Cycle button. Use this display to set the type of flow meter connected to the control. This option setting is identified by "FM" in the upper left-hand corner of the screen. Use the Up and Down buttons to select one of the 7 available settings.



t0.7	Fleck 3/4" Turbine Meter
P0.7	Fleck 3/4" Paddle Wheel Meter
t1.0	Fleck 1" Turbine Meter
P1.0	Fleck 1" Paddle Wheel Meter
t1.5	Fleck 1 1/2" Turbine Meter
P1.5	Fleck 1 1/2" Paddle Wheel Meter
GEn	Generic/Other Meter

17. Meter Pulse Setting (Display Code K)

Press the Extra Cycle button. Use this display to specify the meter pulse setting for a non-standard flow meter. This option setting is identified by "K" in the upper left-hand corner of the screen. Use the Up and Down buttons to enter the meter constant in pulses per unit volume.



(Pulses per Gallon)			
PIPE GENERIC FLOW METER SETTINGS			
SIZE (inches)	TEE GALVANIZED	SADDLE IRON	
1	213	352	
1-1/4	128	177	
1-1/2	94	118	
2	59	67	54
2-1/2		43	38
3		27	23

Note: Make sure to select the proper K-factor for the fitting and pipe size of your system.

AUTO TURBINE METER

METER SIZE	K-FACTOR
1	65
2	15

CL	ACK	METER	

METER SIZE	K-FACTOR
1-1/2	37
2	20
3	8

18. Press the Extra Cycle button to save all settings and exit Master Programming Mode.

CleaverBrooks

USER PROGRAMMING MODE

USER PROGRAMMING MODE OPTIONS			
ABBREVIATIONS	PARAMETER	DESCRIPTION	
DO	Day Override	The timer's override setting	
RT	Regeneration Time	The time of day that the system will regenerate (meter delayed, timeclock, and day-of-week systems)	
Н	Feed Water Hardness	The hardness of the inlet water - used to calculate system capacity for metered systems	
RC	Reserve Capacity	The fixed reserve capacity	
CD	Current Day	The current day of week	

NOTES: Some items may not be shown depending on timer configuration. The timer will discard any changes and exit User Mode if any button is not pressed for sixty seconds.

START-UP

- 1. Press the Up and Down buttons for five seconds while in service, and the time of day is NOT set to 12:01 PM.
- 2. Use this display to adjust the Day Override. This option setting is identified by "DO" in the upper left hand corner of the screen.



3. Press the Extra Cycle button. Use this display to adjust the Regeneration Time. This option setting is identified by "RT" in the upper left hand corner of the screen.



4. Press the Extra Cycle button. Use this display to adjust the Feed Water Hardness. This option setting is identified by "FH" in the upper left hand corner of the screen.



5. Press the Extra Cycle button. Use this display to adjust the Fixed Reserve Capacity. This option setting is 18 identified by "RC" in the upper left-hand corner of the screen.



6. Press the Extra Cycle button. Use this display to set the Current Day of the Week. This option setting is identified by "CD" in the upper left hand corner of the screen.



7. Press the Extra Cycle button to end User Programming Mode.

CleaverBrooks

DIAGNOSTIC PROGRAMMING MODE

USER PROGRAMMING MODE OPTIONS			
ABBREVIATIONS	PARAMETER	DESCRIPTION	
DO	Day Override	The timer's override setting	
RT	Regeneration Time	The time of day that the system will regenerate (meter delayed, timeclock, and day-of-week systems)	
Н	Feed Water Hardness	The hardness of the inlet water - used to calculate system capacity for metered systems	
RC	Reserve Capacity	The fixed reserve capacity	
CD	Current Day	The current day of week	

NOTES: Some items may not be shown depending on timer configuration. The timer will discard any changes and exit User Mode if any button is not pressed for sixty seconds.

START-UP

- 1. Press the Up and Down buttons for five seconds while in service, and the time of day is NOT set to 12:01 PM.
- 2. Use this display to adjust the Day Override. This option setting is identified by "DO" in the upper left hand corner of the screen.



3. Press the Extra Cycle button. Use this display to view the Peak Flow Rate since the last regeneration cycle. This option setting is identified by "PF" in the upper left hand corner of the screen.



4. Press the Extra Cycle button. Use this display to view the Hours in Service since the last regeneration cycle. This option setting is identified by "HR" in the upper left hand corner of the screen.



5. Press the Extra Cycle button. Use this display to view the Volume Used since the last regeneration cycle. This option setting is identified by "VU" in the upper left hand corner of the screen.





DIAGNOSTIC PROGRAMMING MODE

6. Press the Up button. Use this display to view the Reserve Capacity. This option setting is identified by "RC" in the upper left hand corner of the screen.



7. Press the Up button. Use this display to view the Software Version. This option setting is identified by "SV" in the upper left hand corner of the screen.



8. Press the Extra Cycle button to end Diagnostic Programming Mode.



FLOW DIAGRAMS



1 - SERVICE POSITION

Hard water enters the unit at the valve inlet, flows around the lower piston, and down through the mineral in the first tank. Conditioned water enters the center tube through the bottom distributor, flows up through the center tube, around the lower piston, through the meter, and out the valve outlet. The second mineral tank is regenerated and on standby.



2 - TANKS SWITCHING (the meter has initiated a regeneration)

Hard water enters the unit at the valve inlet, flows around the lower piston, through the pipe leading to the second mineral tank, and down through the mineral in the second tank. Conditioned water enters the center tube of the second tank through the bottom distributor, flows up through the center tube, through the pipe leading back to the main valve, around the lower piston, through the meter, and out the valve outlet. The depleted first mineral tank is out of the flow path, and ready for regeneration.



FLOW DIAGRAMS



3 - BACKWASH

Conditioned water from the second mineral tank flows around the lower piston, around the upper piston, through the center of the lower piston, down the center tube, up through the mineral, around the upper piston, and out the drain line.



4 - BRINE DRAW

Conditioned water from the second mineral tank flows around the lower piston, around the upper piston, into the injector housing, and down through the nozzle and throat to draw brine from the brine tank. Brine flows around the upper piston, down through the mineral, into the center tube through the bottom distributor, up the center tube, through the center of the lower piston, through the center of the upper piston, and out through the drain line.



FLOW DIAGRAMS



5 - SLOW RINSE

Conditioned water from the second mineral tank flows around the lower piston, around the upper piston, into the injector housing, down through the nozzle and throat, around the upper piston, down through the mineral, into the center tube through the bottom distributor, up the center tube, through the center of the lower piston, through the center of the upper piston, and out through the drain line.



6 - RAPID RINSE

Conditioned water from the second mineral tank flows around the lower piston, around the upper piston, and down through the mineral in the first tank. Rinse water from the mineral bed enters the center tube through the bottom distributor, flows up the center tube, through the center of the lower piston, through the center of the upper piston, and out through the drain line.



SXT WIRING DIAGRAM





Š

SXT TIMER ASSEMBLY



ltem No.	Quantity	Part No.	Description
1		13881	BRACKET, HINGE TIMER
2	2	11384	SCREW, PHIL, 6-32 X 1/4
3		42732	BRACKET, TIMER, 9000SXT
4	2	13296	SCREW, HEX WSH, 6-20 X 1/2
5		14265	CLIP, SPRING
6		42733	STAND-OFF,TIMER,9000SXT
7		61464	TIMER, SXT, 2510/2750/9000, D/F
7A		19889	HOUSING, CIRCUIT BOARD
7B		42196	CIRCUIT BOARD,SE
7C		42635	COVER,FRONT,SXT,SQUARE
7D		42637	LABEL,DISPLAY,SE



POWERHEAD ASSEMBLY





POWERHEAD PARTS LIST

em No.	Quantity	Part No.	Description
1			Nut, Tinnerman, U Type, 8-32
2	1	11838	Power Cord, 6' Fleck
		11839	Power Cord, 12' Fleck
		40084-12	Power Cord, 12' U.S., Round, 120V Sys 5, 6, 7 &
			2900/3150/3900 #4
		11545-01	Power Cord Assy. 4' Black. Euro w/Terminals
		14678	Power Cord, U.S., 220/60
		19303-01	Power Cord Assy Australian w/Terminals
		40085-12	Power Cord 12'US Round 240V
		19674	Transformer 24V/ 9 6V/A Residential Valves
		41475	Transformer 241/ 9 61/A European
3	1	15202	Harness 9000/9500 Drive
J		1/9202	Harpose 2000
		40041.06	Harposs Low V 0000/0500
4	1	40041-00	
4	I		
D	I		
0 7			
1			
8			Screw, Designer Cover, Thumb 8-32 Blank UV Stable Material
9			Label, Shaft Position
10	2		Ring, Retaining
11			Plate, Ground, 9000/9500
12			Screw, Hex Wsh St, 6 x 1/4 Type "B"
13	2		Screw, Phil Pan, Thread 6-32 x 3/8 Type 23 Zinc
14			Motor, 24V, 50/60 Hz, 1 RPM
		18738	Motor, 120V, 50/60 Hz 1 RPM
		18739	Motor, 220V, 50/60 Hz 1 RPM
15	1	15131	Backplate, 9000
		17784-05	Panel, Control, 9000/9500 ET
16			Screw, Flt Hd Mach, 4-40 x 1 3/8 Steel Zinc Plate
17			Washer, Lock #4, Zinc
18			Switch, Micro
19			Nut, Hex, 4-40 Zinc Plated
20			Screw, Hex Wsh Mach, 10-24 x 3/4 410 S.S.
21	2		Gear Assy, Drive, 3/4" Stroke
22			Strain Relief. Flat Cord Hevco #30-1
23			Ring, Retaining
24			Cam. Triple
		17331	
		17765	Cam Assy Aux Switch 9500
25	1	15368	Tube Cable Guide 2-Tank
20		17337	Tube Cable Guide, 9500
26	2	15372	Washer Thrust 3/8
20	<u>-</u> 1	15216	Meter Cable Assy 15 25"
۰۰۰۰۰۰		15/25	Meter Cable 13.25"
		10420	Mater Cable Assy 20 75" 1 1/2" Std
		10121 01	Motor Cable Assy, 20.75 T 1/2 Stu
		19121-01	Motor Coble Assy, SE, Faudie 0000/0700
		19121-05	Motor Cable Assy, E1, 28 2750/3150 Systemax 4-6
20	2	19/91-01	Mosher Dian 2/8"
∠ŏ	∠		vvasner, Main, 3/8
29	1		
30	1		
31			Screw, Slot Rd Hd Mach, 5-20 x 3/8
	Not Showr	1	
	1		Cover, Designer, 1 Pc Black
	1	60232-112	Cover, Designer, 1 Pc Black w/Left Window
	1		Switch Assy, 9000, Drive Cam
	1		Switch Assy, 9500, Drive Cam



9500 CONTROL VALVE ASSEMBLY





9500 CONTROL VALVE PARTS LIST

Item No.	Quantity	Part No.	Description
1	1	16919-01	. Valve Body
2	16	16101	. Seal
3	12	16638-01	. Spacer
		16638	. Spacer Hot Water
4	1	17110	. Upper Piston
5	2	14309	. Retainer, Piston Rod
	2	15110	. Retainer, Piston Rod, H.W.
6	1	16957	. Upper Piston Rod
7	2	17212	. End Plug Assy.
	2	17212-01	. End Plug Assy. H.W.
8	1	17111	. Lower Piston
9	1	16956	. Lower Piston Rod
10	1	17092	. Spacer Disk
11	1	16955	. End Plug
12		16394	. O-Ring -029
13	.1	14906	End Plate
14	4	15137	Screw, End Plate
		17657	Metric
15	4	17052	Coupling Pipe
16	4	17224	O-Ring -224
17	1	17061	Counting Retainer
18	8	10231	Screw Retainer
10		17659	Metric
10	1	11475	Injector Body Gasket 1600
20	2	17353	90° Copper Elbow
20	<i>2</i>	16916-01	Second Tank Adapter
21	T ク	13577	\cap Ping 226
22	∠ ?	16455	\cap Ping 347
23	∠ 1	1/205	Injector Rody Casket 1700
24	I 1	*1/202	Injector Threat
20	I 1	14002	Injector Pody
20	 1	*1/001	Injector Douy
21	 1	14001	Injector Nozzle
20	I	14003	Injector Screen
29		10229	Injector Cover Gasket
30		11893	. Injector Cover
JI		14004	. Screw, Injector Body
	4	1/000	. IVIELITIC
32	··· I ·······	10221	. All Dispenser
33	··· I ······	1///0	. Injector Body
34		10914-3	. Injector Throat #3, Yellow
35]	10227	. Injector Screen
30		10913-3	. Injector inozzie #3, Yellow
31	∠	10692	. Screw, Injector Body
		1/050	
38		60366	. D.L.F.C. 1" NPT (not shown) - Specify Size
39		1/558	. Spacer
40		19608-15	. Disperser, Upper (not shown)
41	1	11248	. Pin (not shown)
*Injector Th	roat Injector		Color

"Injector I nroat	Injector Nozzie	Size	Color
14802-03	14801-03	.#3C	Yellow
14802-04	14801-04	.#4C	Green
14802-05	14801-05	.#5C	White
14802-06	14801-06	.#6C	Red



Š

9500 SECOND TANK ASSEMBLY



Item No.	Quantity	Part No.	Description	
1	1	13577	O-ring, -226	
2	1		O-ring, -347	
3		10231	Screw, Slot Hex, 1/4 - 20 x 1/	2
4	4	17224	O-ring, -224	



1-1/2" INLINE PLASTIC METER ASSEMBLY



ltem No.	Quantity	Part No.	Description
1	1	17542	Flow Straightener
2			Clip, H, Plastic, 7000
3	1	40577	Turbine Meter Assy, 7000
4	1		Body, Remote Meter
5	2	40951	O-ring, -220
6	2		Connector, 1" NPT, 7000
7	2	40563-10	Connector, 1" BSP, 7000
8	2	40565	Connector, 1 1/4" NPT, 7000
9	2	40565-10	Connector, 1 1/4" BSP, 7000
10	2		Connector, 1" & 1 1/4" Sweat
11	2		Connector, 1 1/4 & 1 1/2" Sweat
12	2	41596	Connector, Brass, 1" NPT
13	2	41596-10	Connector, Brass, 1" BSP
14	2	41597	Connector, Brass, 1 1/2" NPT
15	2		Connector, Brass, 1 1/2" BSP



1-1/2" PLASTIC PADDLE METER



Item No.	Quantity	Part No.	Description
1	1	17569	Body, Meter, 2850/9500
2		13882	Post, Meter Impeller
3		13509	Impeller, Meter
4		13847	O-ring, -137, Std/560CD, Meter
5		14716	Meter Cap Assy, ET/NT
6		12112	Screw, Hex Hd Mach, 10-24 x 1/2
7		17542	Flow Straightener, 1 1/2"
8		12733	O-ring, -132
9		17544	Fitting, 1 1/2" Quick Connector
10	1	17543	Nut, 1 1/2", QC



BRINE SYSTEM - FMR 60M-90M



ltem Number	Description	Part Number
1	Brine Tank 18"x40"/Black Molded Cover - FMR 60M - 90M	A2042028
2	Brine Valve Assembly 474 w/ Aircheck - FMR 65M - 90M	B1179005
3	5" Grid Plate - Plastic - FMR 60M - 90M	A2284002
	6" Grid Extension - Plastic FMR 60M - 90M	A2215007
4	Slotted Brine Well - 4" x 36" - FMR 60M - 90M	A2071003
5	4" Brine Well Cap	A2072003
6	1/2" Overflow Elbow w/ Nut	A2250003
7	3/8" Tubing Kit	B1020001
8	Complete Brine Tank Assembly for FMR 60M - 90M	A2042064



Ľ

BRINE SYSTEM FOR FMR 120M-300M



ltem Number	Description	Part Number
1	Brine Tank 24" x 41" w/ Holes - FMR 120M	B1002039
	Brine Tank 24"x50" w/ Holes - FMR 150M-300M	B1002016
2	24" Diameter 5BW Plastic Grid Plate	A2284007
	Brine Valve (474) for FMR 120	B1180014
	Brine Valve (474) for FMR 150	B1180015
	Brine Valve (474) for FMR 180	B1180016
3	Brine Valve (474) for FMR 210	B1180017
	Brine Valve (474) for FMR 240	B1180018
	Brine Valve (474) for FMR 270	B1180019
	Brine Valve (474) for FMR 300	B1180020
4	1/2" Overflow Elbow w/ Nut	A2250003
5	5" x 46" Drilled Brine Well	B1015008
6	5" Red Cap plug	A2072001
7	1-1/2" SDR or SCH40 DWV Pipe	A2275007
8	1/2" Poly Insert	A2476001
9	1/2" x 3/8" Black Poly Tubing	A2165002
	Complete Brine Tank Assembly for FMR 120M (10" Shelf Height)	B1295015
	Complete Brine Tank Assembly for FMR 150M (13" Shelf Height)	B1295016
	Complete Brine Tank Assembly for FMR 180M (15" Shelf Height)	B1295017
10	Complete Brine Tank Assembly for FMR 210M (18" Shelf Height)	B1295018
	Complete Brine Tank Assembly for FMR 240M (20" Shelf Height)	B1295019
	Complete Brine Tank Assembly for FMR 270M (23" Shelf Height)	B1295020
	Complete Brine Tank Assembly for FMR 300M (26" Shelf Height)	B1295021



Ľ

BRINE SYSTEM FOR FMR 450M



ltem Number	Description	Part Number
1	Brine Tank 30" x 50" w/ Holes - FMR 450M	B1002041
2	5" x 48" Drilled Brine Well	B1015005
3	Brine Valve Assembly 16-1/4" x 24"	B1042007
4	5" Red Cap plug	A2072001
5	1/2" Overflow Elbow w/ Nut	A2250003
6	30" Plastic Top/Bottom Grid Plate	A2284010
7	1-1/2" SDR or SCH40 DWV Pipe	A2275007
8	1/2" Poly Insert	A2476001
9	1/2" x 3/8" Black Poly Tubing	A2165002
10	Complete Brine Tank Assembly for FMR 450M	B1141009



FMR 60M-450M SXT 1-1/2" TWIN ALTERNATING METERED MAINTENANCE

9500 SERVICE ASSEMBLIES



ltem	Quantity	Part Number	Description		
1	1	16919-01 16919-01NP 16919-21 16919-21NP 60080-XX 60039-XX	valve body 9500 NPT, mechanical base valve body 9500 NPT, mechanical base, nickel-plated valve body 9500 BSP/Metric, mechanical base valve body 9500 BSP/Metric, mechanical base, nickel-plated injector assembly (see chart for dash numbers) injector assembly (see chart for dash numbers)		
	·			<i>injector</i> blue #2 yellow #3 green #4 white #5	<i>number</i> 02 03 04 05
4	1	60134 60134-01 60134	seal and spacer kit, top seal and spacer kit, top, hot water seal and spacer kit, top, silicone		
5	1	60108 60108-01	piston assembly, top piston assembly, top		
6	1	60109 60109-01	piston assembly, bottom piston assembly, bottom, hot water		
7	1	60133 60133-01 60133-10	seal and spacer kit, bottom seal and spacer kit, bottom, hot water seal and spacer kit, bottom, silicone		
8	1	16455	O-ring. 347		
9	1	13577	O-ring, 226		
10	1	16955	end plug		
11	1	16394	O-ring, 029		
12	1	14906	end plate		
13	4	15137 17657	screw, hex washer machine, 1-24 x 3/8 screw, hex M5-40, Metric		
Not Shown					
14		16516	tool, seal and spacer stuffer		
15		17623	tool, spacer puller		

36



SERVICE ASSEMBLIES

COVERS

A2103128 Designer with Left Window

BRINE LINE FLOW CONTROLS

 A2389001
 BLFC, .25 GPM, 1600

 A2389002
 BLFC, .50 GPM, 1600

 A2389004
 BLFC, 1.0 GPM, 1600

BRINE VALVE ASSEMBLY

60039-XX Brine Valve, 9500/1700, Cold & HW 180°

A2005085 Brine Valve 9500/1700 Blank A2005025 Brine Valve 9500/1700 2 gpm

PISTON ASSEMBLIES

A2309048 Piston Assy, 9500, Upper, HW 180° A2309049 Piston Assy, 9500, Lower HW, 180°

SEAL & SPACER KITS

 A2435082
 Seal & Spacer Kit, 9500, Upper

 A2435083
 Seal & Spacer Kit, 9500, Lower

SECOND TANK ASSEMBLIES 9500

 A2487017
 Yoke Assy 14" - 16" Tanks

 A2487016
 Yoke Assy 20" Tanks

 A2487015
 Yoke Assy 24" Tanks

 B1700001
 Yoke Assy 30" Tanks

SERVICE EQUIPMENT

A2475002	Stuffer 2850/9500
A2474002	Puller 2850/9500
A2423002	Silicone, 2 oz. Tube
A2164006	Meter Checker Std. Range
A2164005	Meter Checker Ext. Range



TROUBLESHOOTING

ERROR CODES

NOTE: Error codes appear on the In Service display.

ERROR CODE	PROBABLE CAUSE	RECOVER & RESETTING
[Err0]	Drive motor is stalled	Unplug the unit from the power source[
[Err1]	Drive motor is running continuously	When power is restored to the unit, the Err _ display code clears. If the condition causing the error has not been resolved the Err _ code reappears in the four digit display. Do not at-tempt to troubleshoot this problem any further.
[Err2]	There have been more than 99 days since the last Regeneration. If the Day of the Week mode of regeneration is selected and days since last regeneration exceeds 7 days.	Regeneration must occur for the unit to recover, the display to clear and the valve to function normally.
	[7 5]: There have been more than 7 days since the last regen-eration. All individual settings (d1, d2, d3, d4, d5, d6, d7) are set to 0.	[7 5]: To recover from [Err2], the user must initiate a regeneration or set at least one individual day to 1.
[Err3]	Control board memory failure.	Perform a Master Reset. If the error returns, do not attempt to troubleshoot this problem any further.

ERROR DISPLAY EXAMPLE



NOTE: Unit will flash when error exists.

Š



TROUBLESHOOTING 2900 VALVE

PROBLEM	CAUSE	CORRECTION	
1. Softener Fails To Regenerate.	A. Electrical Service To Unit Has Been Interrupted.	A. Assure Permanent Electrical Ser- vice (Check Fuse, Plug, Pull Chain or Switch).	
	B. Timer Is Defective.	B. Replace Timer.	
	C. Power Failure.	C. Reset Time of Day.	
2. Hard Water.	A. By-Pass Valve is Open.	A. Close By-Pass Valve.	
	B. No Salt in Brine Tank	B. Add Salt To Brine Tank and Main- tain Salt Level Above Water Level.	
	C. Injector Screen Plugged.	C. Clean Injector Screen.	
	D. Insufficient Water Flowing Into Brine Tank	 D. Check Brine Tank Fill Time And Clean Brine Line Flow Control If Plugged. 	
	E. Hot Water Tank Hardness.	E. Repeated Flushings Of The Hot Water Tank is Required.	
	F. Leak At Distributor Tube.	F. Make Sure Distributor Tube Is Not Cracked. Check O-Ring And Tube Pilot.	
	G. Internal Valve Leak	G. Replace Seals and Spacers And/ Or Piston.	
	H. Service Adapter Did Not Return To Service.	H. Check Drive Motor And Switch.	
3. Unit Used Too Much Salt	A. Improper Salt Setting.	A. Check Salt Usage and Salt Set-	
	B. Excessive Water in Brine Tank	ting.	
		B. See Problem No. 7.	
4. Loss Of Water Pressure.	A. Iron Buildup In Line To Water Con- ditioner.	A. Clean Line To Water Conditioner.	
	B. Iron Buildup in Water Conditioner.	B. Clean Control and Add Mineral Cleaner to Mineral Bed.	
		Increased Frequency of Regeneration.	
	C. Inlet of Control Plugged Due to Foreign Material Broken Loose From Pipes By Recent Work Done On Plumbing System.	C. Remove Piston and Clean Control.	
5. Loss of Mineral Through Drain Line.	A. Air In Water System.	 A. Assure That Well System Has Proper Air Eliminator Control. Check For Dry Well Condition. 	
	B. Improperly Sized Drain Line Flow Control.	B. Check For Proper Drain Rate.	
6. Iron In Conditioned Water.	A. Fouled Mineral Bed.	A. Check Backwash, Brine Draw And Brine Tank Fill. Increase Fre- quency of Regeneration. Increase Backwash Time.	

CleaverBrooks



TROUBLESHOOTING 2900 VALVE (CONTINUED)

PROBLEM	CAUSE	CORRECTION
7. Excessive Water In Brine Tank.	A. Plugged Drain Line Flow Control.	A. Clean Flow Control.
	B. Plugged Injector System.	B. Clean Injector and Screen.
	C. Timer Not Cycling.	C. Replace Timer.
	D. Foreign Material In Brine Valve.	D. Replace Brine Valve Seat And Clean Valve.
	E. Foreign Material In Brine Line Flow Control.	E. Clean Brine Line Flow Control.
8. Softener Fails To Draw Brine.	A. Drain Line Flow Control Is	A. Clean Drain Line Flow Control.
	Plugged.	B. Clean Injector.
	B. Injector Is Plugged.	C. Clean Screen.
	C. Injector Screen Plugged.	D. Increase Line Pressure To 20 P.S.I.
	D. Line Pressure Is Too Low.	E. Change Seals, Spacers and Piston
	E. Internal Control Leak	Assembly.
	F. Service Adapter Did Not Cycle.	F. Check Drive Motor And Switches.
9. Control Cycles Continuously.	A. Misadjusted, Broken or Shorted Switch.	A. Determine If Switch or Timer Is Faulty and Replace It or Replace Complete Power Head.
10. Drain Flows Continuously.	A. Valve Is Not Programming Cor- rectly.	A. Check Timer Program and Posi- tioning of Control. Replace Power Head Assembly If Not Positioning Properly.
	B. Foreign Material In Control.	B. Remove Power Head Assembly And Inspect Bore. Remove Foreign Material and Check Control In Var- ious Regeneration Positions.
	C. Internal Control Leak	C. Replace Seals and Piston Assembly.

General Service Hints For Meter Control

Problem: Softener Delivers Hard Water.

Cause could be that . . . Reserve Capacity Has Been Exceeded.

Correction: Check salt dosage requirements and reset program wheel to provide additional reserve.

Cause could be that . . . Program Wheel Is Not Rotating With Meter Output

Correction: Pull cable out of meter cover and rotate manually. Program wheel must move without binding and clutch must give positive "clicks" when program wheel strikes regeneration stop. If it does not, replace timer.

Cause could be that . . . Meter Is Not Measuring Flow.

Correction: Check meter with meter checker.



221 Law Street - Thomasville, GA 31792 414-359-0600 - 800-250-5883 info@cleaver-brooks.com - cleaverbrooks.com

Printed in the U.S.A Copyright Cleaver-Brooks, Inc. 750-00321 09/2010