

Torque Arrestor Installation

A quality Merrill Manufacturing™ product made of FDA approved compounds, NOT rubber or other regrind scrap material sold by others that can add a taste or odor to the water.

Placement: The first torque arrestor should be placed no more than 3' above the pump, near the bottom of the well. Then, at intervals of 75' to 100' above the first torque arrestor.

Installation: Place the torque arrestor around the drop pipe so that each half is spaced evenly. Install the lower pipe clamp and tighten. Install the upper pipe clamp (leave loose) and then push down on the torque arrestor to spread the center portion so it fits the inside of the casing. *Just a snug fit, do not spread it so much that it is hard to get it in the casing.* Then tighten the upper clamp. It is very important that the upper clamp is as tight as possible. This will make it easier to remove the pump at a later date.



Copyright © 2015, Merrill Mfg.

[CLICK ANYWHERE on THIS PAGE to RETURN TO SUBMERSIBLE PUMP TORQUE PROBLEMS & SOLUTIONS at InspectApedia.com](#)