

Hubbell-RACO Catalog #s 977, 8977, 8977-5 GRIP-LOK®

- For use with switch boxes that have plaster ears
- For use with new construction and remodeling projects

Installation Instructions:

- Disconnect all power sources
- Trace outline of the box onto the drywall with a marker and saw an opening. Opening should be slightly larger than the box
- Break the GRIP-LOK® into two pieces (Picture 1)
- Insert box with plaster ears into the opening in the drywall
- While pushing the box against the drywall, insert in the direction of the arrow on GRIP-LOK® between the box and drywall (Picture 2)
- Pull up, pivot the remaining portion of the GRIP-LOK® into the gap, and push down. Pull 90 degree tabs towards you until snug
- Bend both tabs into the switch box (Picture 3)
- Repeat other side in same manner
- Back side after installation should look like (Picture 4) and not have any movement. This is for clarification. You may not have access to see this.



Picture 1



Picture 2



Picture 3



Picture 4