CLICK ANYWHERE on THIS PAGE to RETURN to REFRIGRATOR REPAIR at InspectApedia.com

Whirlpool refrigerator error codes

Searspartsdirect.com/diy/error-codes/refrigerator-repair/1234589/whirlpool-refrigerator/1198

d on the refrigerator display

Air damper is stuck

Check/Repair

Unplug the refrigerator and examine the air damper that controls air flow from the freezer compartment to the refrigerator compartment for damage. If the air damper is broken, replace it.

How-to help <u>How to replace a diffuser in a side-by-side refrigerator</u>

Possible parts Air damper

C on the refrigerator display

Refrigerator compartment thermistor (temperature sensor) failure

C on the freezer display

Freezer compartment thermistor failure

CF on the freezer display

Communication failure between main control board and user interface control

18 degrees F (or -8 degrees C) temperature reading on the freezer display

Over-temperature condition