



Use and Care Guide Soffit Exhaust Vent

Item #608-956
Model #SEVHD

EVERBILT

TOOLS REQUIRED



HARDWARE INCLUDED



Guía de uso y cuidado Respiradero de escape de sofito

Artículo #608-956
Modelo # SEVHD

EVERBILT

HERRAMIENTAS NECESARIAS




HERRAJE INCLUIDO



Installation


1 ADJUSTING THE SOFFIT EXHAUST VENT

- If necessary, adjust your soffit exhaust vent to fit your duct size. For 5 in. diameter duct, use a utility knife to cut off the 4 in. ring. For a 6 in. duct, remove the 4 in. / 5 in. collar adapter.




2 TRACING THE CIRCLE TEMPLATE

- Cut out the circle template, and position it in the midpoint of the soffit. Trace the circle template (see the reverse side of the page) and cut the hole.




3 POSITIONING THE DUCT THROUGH THE SOFFIT

- From the bathroom or kitchen fan, feed the duct through the opening in the soffit.




4 CLEANING THE LINT TRAP

- Connect the duct to the soffit exhaust vent and clamp it to the appropriate ring size (determined in step 1).




5 PLACING THE PRODUCT INTO THE SOFFIT

- Place the duct and soffit into the opening, and ensure the facing is flush against the soffit panel.



6 SECURING THE SOFFIT EXHAUST VENT

- Fasten the soffit exhaust vent to the soffit panel using the screws provided.



Safety Information

This soffit exhaust vent is intended for use on soffit panels at least 16 in. wide with a vertical clearance of at least 6 in. high. Before beginning installation, make sure the soffit area is free of insulation and debris.

Warranty

WHAT IS COVERED

All merchandise is warranted to be free from defects in workmanship and material for one year from the date of purchase. This includes normal wear and performance failure on items. The manufacturer will replace or repair at their option.

WHAT IS NOT COVERED


This warranty only covers normal wear and performance failure. It does not cover any malfunction, performance failure, or defect arising from the misuse, abuse, neglect, or modification of the product. Any damage or malfunction inflicted upon the product by the user or other external sources, or any failure to comply with the warnings and instructions, is not covered.

For further assistance visit www.HomeDepot.com.

Instalación


1 CÓMO AJUSTAR EL RESPIRADERO DE ESCAPE DE SOFITO

- Si es necesario, ajuste el respiradero de escape de sofito para que se adecue al tamaño del conducto. Para un conducto de 5 pulg. de diámetro, use una navaja para cortar el anillo de 4 pulg. Para un conducto de 6 pulg., retire el adaptador de 4 pulg./5 pulg. del collar.




2 CÓMO TRAZAR LA PLANTILLA CIRCULAR

- Corte la plantilla circular y colóquela en el centro del sofito. Trace la plantilla circular (mire el reverso de esta página) y corte el orificio.




3 CÓMO POSICIONAR EL CONDUCTO A TRAVÉS DEL SOFITO

- Desde el ventilador del baño o de la cocina, haga pasar el conducto a través de la abertura en el sofito.




4 CÓMO CONECTAR EL CONDUCTO

- Conecte el conducto al respiradero de escape de sofito y fíjelo con el anillo del tamaño adecuado (según lo determinó en el paso 1).




5 CÓMO COLOCAR EL PRODUCTO EN EL SOFITO

- Coloque el conducto y el sofito en la abertura y asegúrese de que la parte frontal quede bien alineada contra el panel del sofito.



6 CÓMO ASEGURAR EL RESPIRADERO DE ESCAPE DE SOFITO

- Fije el respiradero de escape de sofito al panel del sofito usando los tornillos que se suministran.



Información de seguridad

Este respiradero de escape de sofito está diseñado para usarse en paneles de por lo menos 16 pulg. de ancho con un espacio vertical de por lo menos 6 pulg. de altura. Antes de comenzar la instalación, asegúrese de que el área del sofito esté libre de material de aislamiento y desechos.

Garantía

¿QUÉ SE CUBRE?

Toda la mercancía se garantiza contra defectos de fabricación y de los materiales durante un año a partir de la fecha de compra. Esto incluye el desgaste y las fallas en el desempeño normales de los artículos. El fabricante reemplazará o reparará el artículo a su criterio.

¿QUÉ NO SE CUBRE?

Esta garantía cubre únicamente el desgaste y las fallas en el desempeño normales. No cubre el mal funcionamiento, las fallas en el desempeño ni los defectos que surjan debido al mal uso, el abuso, la negligencia o la modificación del producto. No están cubiertos los daños ni el mal funcionamiento que se cause al producto por parte del usuario o otras fuentes externas, ni las fallas debidas al incumplimiento de las advertencias y las instrucciones.

Para obtener más ayuda visite www.HomeDepot.com.

